

# SW-1016

1x16 Optical Switch with Power Monitor

# SW-1016 Optical Switch with Power Monitor User's Manual



## Revision History

<b>Document Revision</b>	<b>Date</b>	<b>Description</b>
1.0	July 2015	Initial Release

# Table of Contents

Revision History .....	2
1.0 Scope .....	6
2.0 Operational Overview .....	6
2.1 Default Operational Settings and Non-Volatile Memory .....	7
3.0 Description of All Items Included in SW-1016 Packaging .....	8
4.0 USB GUI Software Installation and Initial Power-On .....	8
4.1 USB GUI Installation .....	8
4.2 USB Connection to SW-1016 Module and Initial Power-On .....	10
5.0 Ethernet Based Control/Status Setup and Initial Power-On .....	11
5.1 Initial Setup for Ethernet Control/Status .....	12
5.2 IP Address Reset Button (on bottom side of module) .....	14
6.0 USB GUI Operation .....	15
6.1 Getting Started with the USB GUI .....	15
6.2 Main Menu Control and Status Functions .....	15
6.2.1 Primary Status Display .....	15
6.2.2 Primary Control Functions .....	16
7.0 Ethernet Browser GUI Operation .....	20
7.1 Optical Control/Status .....	20
7.1.1 Display of Status Parameters .....	20
7.2 System Status .....	25
7.3 Ethernet Setup .....	25
7.4 Revision/Update .....	26
8.0 Optical and Electrical Specifications .....	28
9.0 Mechanical Dimensions .....	28
10.0 Part Numbers for Ordering .....	29

## List of Figures

Figure 2.0-1 - SW-1016 Functional Block Diagram and Internal Connectivity .....	7
Figure 3.0-1 - SW-1016 Packaging Box .....	8
Figure 3.0-2 - ESD Container with SW-1016 Inside .....	8
Figure 3.0-3 - AC/DC Plug Adapter, Ethernet Cable, USB Cable, and CD-ROM with USB GUI and User's Manual .....	8
Figure 4.1-1 - SW-1016 USB GUI Installation Folder Contents on CD-ROM .....	9
Figure 4.1-2 - Windows User Account Control Notification .....	9
Figure 4.1-3 - USB GUI Installation Progress Window .....	10
Figure 4.1-4 - USB GUI Installation Complete Window .....	10
Figure 4.2-1 - Example of SW-1016 USB GUI Main Menu .....	11
Figure 4.2-2 - Error Message Displayed When SW-1016 is Not Connected to USB Port .....	11
Figure 5.0-1 - Two Methods of Using an Ethernet Interface to the SW-1016 Module .....	12
Figure 5.2-1 - SW-1016 IP Address Reset Button Location .....	14
Figure 6.1-1 - How to Move and Close the Main Menu Window, Open Device Info Window .....	15
Figure 6.2.1-1 - Main Menu Shown in both dBm and Watts .....	16
Figure 6.2.2-1 - Key Control Functions and Windows on the Main Menu .....	16
Figure 6.2.2-2 - LOS Indicator is Red When Optical Power Level is Less than LOS Level .....	17
Figure 6.2.2-3 - Relative Power Mode is Selected and the Reference Power Level Displayed .....	17
Figure 6.2.2-4 - Min/Max Mode Using dBm and Watts .....	18
Figure 6.2.2-5 - Both Relative Power Mode and Min/Max Can Be Simultaneously Enabled .....	18
Figure 6.2.2-6 - LOS Continues to Function Normally When Both Relative Power Mode and Min/Max Are Simultaneously Enabled .....	19
Figure 7.1.1-1 - Type Appropriate IP Address of Module to Access Home Page .....	20
Figure 7.1.1-2 - Optical Control and Status Page .....	21
Figure 7.1.1-3 - User Selects Watts to be Used for Displaying Optical Power .....	21
Figure 7.1.1-4 - User Enters -20.0 dBm for LOS Level and the LOS Alarm is Activated .....	22
Figure 7.1.1-5 - Relative Power Mode is Selected and the Reference Power Level Displayed .....	23
Figure 7.1.1-6 - Min/Max Mode Using dBm and Watts .....	23
Figure 7.1.1-7 - Both Relative Power Mode and Min/Max Can Be Simultaneously Enabled .....	24
Figure 7.1.1-8 - Continuous Update Box Should Remain Checked Under Most Conditions .....	24
Figure 7.2-1 - System Status Information .....	25
Figure 7.3-1 - Ethernet Setup Controls with Factory Default IP Address .....	25
Figure 7.4-1 - Firmware Revision/Update Page, Browse to a File and Click Update to Begin Downloading New Firmware .....	27
Figure 9.0-1 - SW-1016 Module Mechanical Dimensions .....	28

## List of Tables

Table 2.1-1 - Default Operational Settings as Shipped from the Factory.....	7
Table 4.1-1 - Step-by-Step Instructions to Install the USB GUI.....	9
Table 5.1-1 - Ethernet Port Setup for Standalone Computer Operation with SW-1016 .....	12
Table 5.1-2 - SW-1016 Ethernet Port Setup for Operation with Ethernet Router Using Static IP.....	13
Table 5.1-3 - SW-1016 Ethernet Port Setup for Operation with Ethernet Router Using Dynamic IP..	14
Table 7.3-1 - Ethernet Configuration Description of Parameters.....	26
Table 8.0-1 – Optical Power Monitor Specifications .....	28
Table 8.0-2 - Electrical, Mechanical, and Environmental Specifications.....	28

## 1.0 Scope

This SW-1016 User's Manual gives an overview of the hardware and software design and describes module installation, configuration, alarms, and operator control and status capability.

## 2.0 Operational Overview

The SW-1016 module is a 1x16 MEMS based, hitless, bidirectional optical switch with in-line power monitor in a compact, portable, cost-effective solution for use in a variety of applications. A detailed block diagram showing the internal hardware connectivity of this module is shown in Figure 2.0.


The SW-1016 module can be USB powered and connected directly to a Windows based computer running the custom graphical user interface (GUI) software. Additionally, the module has an Ethernet GUI so the SW-1016 can be controlled via a 10/100BaseT link using either Static or Dynamic IP addressing. The Ethernet GUI uses a standard HTML browser (e.g. Firefox, Chrome, Internet Explorer) to provide the user interface and the various control and status HTML pages are integrated into the microcontroller's firmware.

Using either the USB GUI or the HTML browser GUI, the operator can place the optical switch into any position, one through sixteen, or command it to make no connection. The switch performs fast, hitless switching and allows for bidirectional operation.

The single mode fiber configuration of the in-line power monitor is calibrated at 1310 nm, 1550 nm, and 1608 nm wavelengths allowing the user to easily select any one of those bands. The optical power level is measured using a 2% bidirectional tap to minimize insertion loss. An onboard temperature sensor allows the power monitoring circuitry to be calibrated during production test to provide measurement resolution of  $\pm 0.01$  dB and linearity (relative accuracy) of  $\pm 0.1$  dB over an operating temperature range of 0°C to 40°C.

The user can switch from Absolute to Relative power display mode in order to compensate for a specific amount of loss in a given test setup. When Relative mode is selected, the reference power level is displayed in dBm under the Relative offset power on the GUI. Both in Absolute and Relative modes, the user can also select to display the minimum and maximum power detected at the input. This is useful for detecting power variations during unattended operation.

It is possible to perform remote, time stamped, switch position and power monitor data logging using a SW-1016 application written for Windows and for Linux. This application uses the IP address of the module to gather the power monitoring data every second and write that data, along with the host computer's system time, to a .csv file. This allows the user to remotely collect and track module information over long periods of time.



**Figure 2.0-1 - SW-1016 Functional Block Diagram and Internal Connectivity**

## 2.1 Default Operational Settings and Non-Volatile Memory

The SW-1016 module always saves the switch position, Min/Max selection, Rx LOS threshold, and IP address in non-volatile memory (NVM) regardless of whether the USB GUI or the Ethernet interface is used for control and status. The Absolute/Relative mode and the Units display are not saved in NVM and always power-on in Absolute mode with a dBm display.

The SW-1016 module is shipped from the factory with the default settings given in Table 2.1-1. This module is setup to be “ready for operation” as soon as it is powered on so the module can be placed directly into service without changing any parameters if desired.

**Table 2.1-1 - Default Operational Settings as Shipped from the Factory**

Control Function	Default Setting	Description
Switch Position	1	Switch position 1
Min/Max	Off	Min/Max is turned off
Mode	Absolute	Absolute power levels are displayed
Optical Power Display	dBm	Power is displayed in dBm
Loss of Signal (LOS) Level	-30 dBm	Typical setting for LOS
Ethernet Mode	Static	Static IP address mode
IP Address	192.168.1.234	Default IP address
IP Subnet	255.255.255.0	Default IP subnet
IP Gateway	192.168.1.1	Default IP gateway

### 3.0 Description of All Items Included in SW-1016 Packaging

The photos below show all the items which are included with the SW-1016. There is an Ethernet cable, a USB cable, and an AC/DC power adapter along with a CD-ROM containing the USB GUI installation files and user's manual.



Figure 3.0-1 - SW-1016 Packaging Box



Figure 3.0-2 - ESD Container with SW-1016 Inside



Figure 3.0-3 - AC/DC Plug Adapter, Ethernet Cable, USB Cable, and CD-ROM with USB GUI and User's Manual

### 4.0 USB GUI Software Installation and Initial Power-On

This paragraph describes the USB GUI installation and power-on procedure so if only the Ethernet interface is planned to be used, please skip to paragraph 5.0.


#### 4.1 USB GUI Installation

Before initially powering on the SW-1016 module, the USB GUI should be installed onto a Windows 7, XP, or 8 computer. The included CD-ROM contains all of the required installation files. Proceed to install the USB GUI by following the instructions in Table 4.1-1. Several screen captures of the installation process are shown in the figures below.


The installation procedure will install the SW-1016 GUI application program as well as the National Instruments Run Time Engine and all USB drivers needed to communicate with the SW-1016 module. Therefore, no additional driver or software installation is necessary.

**Table 4.1-1 - Step-by-Step Instructions to Install the USB GUI**


Step #	Description
1	Insert the disk into the Windows computer's DVD drive, navigate into the <b>USB GUI</b> folder and verify the file structure of the CD-ROM looks as shown in Figure 4.1-1.
2	Double click on the <b>Install_SW1016 GUI</b> file and the Windows User Account Control message shown in Figure 4.1-2 will appear. Click Yes to continue to install the software.
3	While the installation is in progress for approximately 4 minutes, the small window shown in Figure 4.1-3 will appear to indicate the installation process is in progress.
4	Once installation is complete, the window in Figure 4.1-4 will be shown to remind the user to restart the computer at the earliest convenience. The user can click OK to continue, the computer will not restart until the user specifically commands a Windows restart.
5	Whenever convenient, restart the computer.
6	Proceed to paragraph 4.2 of this document to continue the setup procedure.




**Figure 4.1-1 - SW-1016 USB GUI Installation Folder Contents on CD-ROM**



**Figure 4.1-2 - Windows User Account Control Notification**



**Figure 4.1-3 - USB GUI Installation Progress Window**




**Figure 4.1-4 - USB GUI Installation Complete Window**

#### ***4.2 USB Connection to SW-1016 Module and Initial Power-On***


Although not required, it is recommended the SW-1016 module not be connected to any optical sources the first time it is powered on so proper operation of the LED indicator can be checked. Keeping the dust caps on the two optical connectors (and once the GUI application has been installed on a Windows computer) plug the USB cable into the computer and into the SW-1016 module's USB port. After a few seconds, the computer should indicate it recognizes the module with the typical Windows USB connection sound. The LED on the top side of the module should illuminate to a red color indicating that DC power is being supplied to the module and that the optical power input is below the Loss-of-Signal (LOS) level. If the LED does not illuminate, it is an indication that DC power is not being supplied to the module through the USB port.

Open the GUI application by clicking on the **Windows Start** icon, **All Programs**, **TPC** folder, and finally the **SW\_1016** application. The GUI will open and the main menu window will display and look similar to that shown in Figure 4.2-1. At this point the module is ready to be controlled and an optical signal can be applied to the optical FC connector labeled "IN". The output signal is available on the selected fiber at the optical MTP connector labeled "OUT". Note that the module supports bidirectional operation even though the single fiber connector is labeled "IN" and the 16 fiber connector is labeled "OUT". Please go to paragraph 6.0 in order to obtain more details regarding specific operation of the USB GUI application.



**Figure 4.2-1 - Example of SW-1016 USB GUI Main Menu**

If the GUI application is opened when no SW-1016 module is connected to the USB port, the error message shown in Figure 4.2-2 will appear. In this case, close the GUI, connect a SW-1016 to the USB port, then re-open the GUI application.




**Figure 4.2-2 - Error Message Displayed When SW-1016 is Not Connected to USB Port**

## 5.0 Ethernet Based Control/Status Setup and Initial Power-On

An external computer with a 10/100BaseT Ethernet port is required to provide control and status for the SW-1016 module when using the standard HTML browser (Chrome, Firefox, Internet Explorer) based GUI. When using Ethernet communications to control/status the SW-1016 module, there is no other special software required, the browser (Chrome, Firefox, Internet Explorer) is sufficient.

There are two primary ways to configure the hardware connection between the external computer and the SW-1016 module, both are shown in Figure 5.0-1. Use the included Ethernet cable and setup the hardware connection in either of the two ways shown in the figure.



**Figure 5.0-1 - Two Methods of Using an Ethernet Interface to the SW-1016 Module**

Although not required, it is recommended the SW-1016 module not be connected to any optical sources the first time it is powered on so proper operation of the LED indicator can be checked. Keeping the dust caps on the two optical connectors, plug the included AC/DC power adapter into a 120 VAC wall outlet and into the SW-1016 module’s “DC” port. After a few seconds, the LED on the top side of the module should illuminate to a red color indicating that DC power is being supplied to the module and that the optical power input is below the Loss-of-Signal (LOS) level. If the LED does not illuminate, it is an indication that DC power is not being supplied to the module through the AC/DC power adapter.

### 5.1 Initial Setup for Ethernet Control/Status

The SW-1016 module is shipped in Static IP address mode to allow communication via a direct connection to a standalone computer as shown in the upper block diagram of Figure 5.0-1. In order to initially communicate with the SW-1016, setup the Ethernet port of the standalone computer as given in Table 5.1-1.

**Table 5.1-1 - Ethernet Port Setup for Standalone Computer Operation with SW-1016**

#	Description
1	Set up the properties of your computer’s LAN Ethernet connection by navigating as follows: <ul style="list-style-type: none"> <li>- Select <b>Start, Control Panel, Network and Internet, Network and Sharing Center</b>, then click on <b>Change adapter settings</b> on the left side</li> <li>- Right click on your <b>Local Area Connection</b> and select <b>Properties</b></li> <li>- Click on <b>Internet Protocol Version 4 (TCP/IPv4)</b> and select <b>Properties</b></li> <li>- Click on <b>Use the following IP address: type IP address 192.168.1.235, Subnet Mask 255.255.255.0, Default Gateway (leave blank)</b></li> <li>- Click on <b>Use the following DNS server addresses: Preferred DNS Server (leave blank), Alternate DNS server (leave blank)</b></li> <li>- Click OK to exit all the windows</li> </ul>
2	Connect the Ethernet cable from your computer directly to the module
3	Open a Chrome, Firefox, or Internet Explorer browser window
4	In the browser’s URL window, type 192.168.1.234 and wait for the SW-1016 main screen to appear.
5	Click on the menu for Optical Control/Status

If desired, the SW-1016 can be fully controlled using only a standalone computer and its HTML browser. If that is the desired method of control, please proceed to paragraph 7.0 which describes the various screens, control, and status capable of being implemented with the HTML browser.

In order to connect the SW-1016 module to an Ethernet router for remote control and status, setup the module as described in Table 5.1-2 if a Static IP address is desired, or as described in Table 5.1-3 if a Dynamic IP address is desired.

**Table 5.1-2 - SW-1016 Ethernet Port Setup for Operation with Ethernet Router Using Static IP**


#	Description
1	Click on <b>Ethernet Setup</b> at the top menu bar.
2	Select <b>Static</b> for the <b>Ethernet Mode</b> drop down menu.
3	Type in the new, desired <b>IP Address</b> , <b>IP Subnet</b> , and <b>IP Gateway</b> settings which are to be used with your Ethernet Router.
4	Once all the desired settings are correct, click <b>Apply Settings</b> . Please note that once Apply Settings is clicked, you will no longer be able to communicate with the module until it is connected to the Ethernet Router on which the new settings are appropriate. If there are ever problems accessing the module, the SW-1016 can always be placed back into its factory default state for the Ethernet Settings using the IP Address Reset button on the bottom side of the module. See paragraph 5.2 for more details.
5	Connect the Ethernet cable from the Ethernet Router directly to the SW-1016 module.
6	Using a computer which can also access this Ethernet Router, open a Chrome, Firefox, or Internet Explorer browser window.
7	In the browser's URL window, type the newly entered Static IP address of the module and wait for the SW-1016 main screen to appear.
8	Proceed to paragraph 7.0 which describes the various screens, control, and status capable of being implemented with the HTML browser.

**Table 5.1-3 - SW-1016 Ethernet Port Setup for Operation with Ethernet Router Using Dynamic IP**

#	Description
1	Click on <b>Ethernet Setup</b> at the top menu bar.
2	Select <b>DHCP</b> for the <b>Ethernet Mode</b> drop down menu. It is not necessary to change the <b>IP Address, IP Subnet, and IP Gateway</b> settings.
3	Once <b>DHCP</b> is selected, you will no longer be able to communicate with the module until it is connected to the Ethernet Router setup for Dynamic IP addressing. If there are ever problems accessing the module, the SW-1016 can always be placed back into its factory default state for the Ethernet Settings using the IP Address Reset button on the bottom side of the module. See paragraph 5.2 for more details.
4	Connect the Ethernet cable from the Ethernet Router directly to the SW-1016 module.
5	Power off the module for 10 seconds, then re-apply DC power to the module.
6	There are two ways in which to determine the dynamic IP address once it has been assigned to the module. The first is to use the Admin function of the Ethernet Router and determine the Dynamic IP address which has been assigned to the SW-1016 module. The second is to connect to the USB port of the module and open the USB GUI. Click on the Device Info box and the Device Information window will display the current IP address.
7	Using a computer which can also access this Ethernet Router, open a Chrome, Firefox, or Internet Explorer browser window.
8	In the browser's URL window, type the newly found Dynamic IP address of the module and wait for the SW-1016 main screen to appear.
9	Proceed to paragraph 7.0 which describes the various screens, control, and status capable of being implemented with the HTML browser.

### ***5.2 IP Address Reset Button (on bottom side of module)***

The IP address reset button is located on the bottom side of the module, see Figure 5.2-1, and is recessed so it is not possible to inadvertently reset the IP address. The tip of an ordinary ball point pen can be used to press this reset button. Pressing and holding the IP Address Reset button for at least 1 second reconfigures the 10/100BaseT Ethernet port to its default state which is: Static IP address mode, IP address = 192.168.1.234, Subnet mask = 255.255.255.0, Default gateway = 192.168.1.254. During the execution of this command, the optical communications link is not interrupted.



**Figure 5.2-1 - SW-1016 IP Address Reset Button Location**

## 6.0 USB GUI Operation

### 6.1 Getting Started with the USB GUI

Once the USB GUI application has been started using the steps described previously in paragraph 4.2, the SW-1016 Main Menu will appear. This window remains visible until the application is closed by clicking the “X” inside the red box in the upper right area of the Main Menu or by removing the USB cable from the SW-1016 module. This GUI application can only be active and running when a SW-1016 is physically connected to the computer using a USB cable. Otherwise, the application will automatically close if no module connection is detected.

The Main Menu window can be moved and repositioned on the screen by clicking the bar at the top of the window and dragging it to a different location. The size of this window cannot be changed.

By clicking on Device Info, a new window is opened to show specific module information such as the model number, part number, serial number, firmware and GUI revisions. This window cannot be repositioned and is closed by clicking the red box in the upper right corner.

Figure 6.1-1 shows an example Main Menu window with several key areas highlighted.





Figure 6.1-1 - How to Move and Close the Main Menu Window, Open Device Info Window

### 6.2 Main Menu Control and Status Functions

#### 6.2.1 Primary Status Display

All of the critical status information from the SW-1016 module is shown on the Main Menu as highlighted in Figure 6.2.1-1.




**Figure 6.2.1-1 - Main Menu Shown in both dBm and Watts**

The optical power is monitored using a 2% tap (bidirectional) to minimize insertion loss. The optical power is displayed in its designated location and can be shown in either dBm or Watts based on the user's selection of Units. The standard dynamic range is -50 dBm to +10 dBm but can be shifted based on customer requests so please contact TPC if different power monitoring ranges are desired.

The minimum power level displayed for power monitor is equal to the lowest value of the range which is -50 dBm. A temperature sensor is mounted on the PCB and its value in degrees Celsius is continuously updated on the display.

## 6.2.2 Primary Control Functions


The key control functions of the SW-1016 module are highlighted on the Main Menu shown in Figure 6.2.2-1.



**Figure 6.2.2-1 - Key Control Functions and Windows on the Main Menu**


The Loss of Signal (LOS) level can also be edited by the user and has a range from -50 dBm to +10 dBm (for the standard configuration). To edit this value, click inside the box, make the necessary edits, then press Enter to send the changes to the module. The LOS indicator on the GUI will be a green color whenever the incoming optical signal is at a greater power level than the LOS

level. The indicator will be red whenever the incoming optical signal level is less than the LOS level as shown in Figure 6.2.2-5. In this case the user has entered -20.0 dBm as the desired LOS level.




**Figure 6.2.2-2 - LOS Indicator is Red When Optical Power Level is Less than LOS Level**

The SW-1016 can be placed into Relative power mode as shown in Figure 6.2.2-3. In this mode, the Reference power level is displayed in the center of the main window and the deviation from that Reference level is prominently displayed directly under "Input Power". The Units cannot be changed and will always be "dBm" when operating in Relative power mode. A new Reference level can be captured by clicking the Reset button under the Min/Max and Ref label.




**Figure 6.2.2-3 - Relative Power Mode is Selected and the Reference Power Level Displayed**

When the Min/Max mode is selected by the user, the minimum and maximum optical power levels are captured and displayed as shown in Figure 6.2.2-4. In this Figure, two different windows are shown representing both a "dBm" display and a "Watts" display. In either case, the Min/Max captured values are reset whenever the user clicks the Reset button under the Min/Max and Ref label.




**Figure 6.2.2-4 - Min/Max Mode Using dBm and Watts**

If desired, both the Relative power mode and Min/Max can be enabled simultaneously as shown in Figure 6.2.2-5. All of the power information is conveniently displayed in the main window.



**Figure 6.2.2-5 – Both Relative Power Mode and Min/Max Can Be Simultaneously Enabled**

The LOS indicator still functions normally when both the Relative power mode and Min/Max mode are enabled simultaneously as shown in Figure 6.2.2-6. In this case, the switch position has been set to “5” and the calibrated wavelength selection is 1310 nm (other possible wavelength selections are 1550 nm and 1608 nm).



**Figure 6.2.2-6 – LOS Continues to Function Normally When Both Relative Power Mode and Min/Max Are Simultaneously Enabled**


## 7.0 Ethernet Browser GUI Operation

As mentioned previously, the SW-1016 module includes embedded web pages as part of its internal microcontroller's firmware. Standard HTML browsers such as Chrome, Firefox, and Internet Explorer can be used to provide control and status of the module. After completing the Ethernet port setup for operation with a standalone local computer or with an Ethernet Router (Tables 5.1-1, 5.1-2, or 5.1-3), the SW-1016 module can be controlled and monitored using the steps described in paragraphs 7.1 through 7.4.

### 7.1 Optical Control/Status

#### 7.1.1 Display of Status Parameters

Use a standard browser such as Chrome, Firefox, or Internet Explorer to communicate with the SW-1016 module by typing the appropriate IP address (e.g. 192.168.1.234) in the URL window of the browser as shown in Figure 7.1.1-1.



**Figure 7.1.1-1 - Type Appropriate IP Address of Module to Access Home Page**

Click on the **Optical Control/Status** area of the menu bar to access the page which shows all the real time status parameters and allows for control of optical functions. An example of the Optical Control and Status window is given in Figure 7.1.1-2.

Optical Control/Status	System Status	Ethernet Setup	Revision/Update
Optical Control and Status			
Status Parameter	Status		
Power	-16.42 dBm		
Switch Position	16		
Loss of Signal (LOS)	OK		
Max	---		
Min	---		
Reference	---		
Temperature (°C)	30.1		
<input checked="" type="checkbox"/> Continuous Update			
Control Function	Setting		
Desired Switch Position	16		
Optical Power Display	dBm		
Loss of Signal (LOS) Level (dBm)	-20.0		
Wavelength	1550		
Mode	Absolute		
Min/Max	Off		
Min/Max and Reference Reset	Reset		

**Figure 7.1.1-2 - Optical Control and Status Page**

The SW-1016 performs in-line power monitoring of one channel of optical input power using a bidirectional 2% tap to minimize insertion loss. The optical power is displayed in either dBm or Watts based on the user's selection of Units. Figure 7.1.1-3 shows Watts being selected by the user and the appropriate power level being displayed.

Optical Control/Status	System Status	Ethernet Setup	Revision/Update
Optical Control and Status			
Status Parameter	Status		
Power	0.0751675 mW		
Switch Position	4		
Loss of Signal (LOS)	OK		
Max	0.0804315 mW		
Min	0.0380022 mW		
Reference	---		
Temperature (°C)	31.7		
<input checked="" type="checkbox"/> Continuous Update			
Control Function	Setting		
Desired Switch Position	4		
Optical Power Display	Watts		
Loss of Signal (LOS) Level (dBm)	-20.0		
Wavelength	1550		
Mode	Absolute		
Min/Max	On		
Min/Max and Reference Reset	Reset		

**Figure 7.1.1-3 – User Selects Watts to be Used for Displaying Optical Power**

The standard optical power monitor range is -50 dBm to +10 dBm but can be shifted based on customer requests so please contact TPC if a different power monitoring range is desired. The minimum power level displayed for the power monitor is equal to the lowest value of the range which is -50 dBm for the standard configuration.

The Loss of Signal (LOS) level can also be edited by the user and has a range from -50 dBm to +10 dBm (for the standard configuration). To edit this value, click inside the box as shown in Figure 7.1.1-4, make the necessary edits, then press Enter to send the changes to the module. The LOS indicator on the GUI will be a green color whenever the incoming optical signal is at a greater power level than the LOS level and will be red whenever the incoming optical signal level is less than or equal to the LOS level as given in Figure 7.1.1-4.

The screenshot shows a web interface with a navigation bar at the top containing 'Optical Control/Status', 'System Status', 'Ethernet Setup', and 'Revision/Update'. The main content area is titled 'Optical Control and Status' and contains two tables.

The first table, 'Status Parameter' vs 'Status', has the following data:

Status Parameter	Status
Power	-24.89 dBm
Switch Position	16
Loss of Signal (LOS)	ALARM
Max	---
Min	---
Reference	---
Temperature (°C)	30.4

Below this table is a checkbox labeled 'Continuous Update' which is checked.


The second table, 'Control Function' vs 'Setting', has the following data:

Control Function	Setting
Desired Switch Position	16
Optical Power Display	dBm
Loss of Signal (LOS) Level (dBm)	-20.0
Wavelength	1550
Mode	Absolute
Min/Max	Off
Min/Max and Reference Reset	Reset

Red arrows from external text point to the 'ALARM' status in the first table and the '-20.0' value in the second table.


**Figure 7.1.1-4 – User Enters -20.0 dBm for LOS Level and the LOS Alarm is Activated**

The SW-1016 can be placed into Relative power mode as shown in Figure 7.1.1-5. In this mode, the Reference power level is displayed in the far right column and the deviation from that Reference level is displayed directly under "Power". The Units cannot be changed and will always be "dBm" when operating in Relative power mode. A new Reference level can be captured by clicking the Reset button in the Min/Max and Reference Reset row.



**Figure 7.1.1-5 - Relative Power Mode is Selected and the Reference Power Level Displayed**

When the Min/Max mode is selected by the user, the minimum and maximum optical power levels are captured and displayed as shown in Figure 7.1.1-6. In this Figure, two different windows are shown representing both a “dBm” display and a “Watts” display. In either case, the Min/Max captured values are reset whenever the user clicks the Reset button under the Min/Max and Ref label.



**Figure 7.1.1-6 - Min/Max Mode Using dBm and Watts**

If desired, both the Relative power mode and Min/Max can be enabled simultaneously as shown in Figure 7.1.1-7. All of the power information is conveniently displayed in the main window.

Optical Control/Status	System Status	Ethernet Setup	Revision/Update
Optical Control and Status			
Status Parameter	Status		
Power	0.52 dB		
Switch Position	4		
Loss of Signal (LOS)	OK		
Max	-11.97 dBm		
Min	-14.02 dBm		
Reference	-12.98 dBm		
Temperature (°C)	31.3		
<input checked="" type="checkbox"/> Continuous Update			
Control Function	Setting		
Desired Switch Position	4		
Optical Power Display	dBm		
Loss of Signal (LOS) Level (dBm)	-20.0		
Wavelength	1550		
Mode	Relative		
Min/Max	On		
Min/Max and Reference Reset	Reset		

**Figure 7.1.1-7 – Both Relative Power Mode and Min/Max Can Be Simultaneously Enabled**

The default configuration of the status display is to continuously update all status so the Continuous Update box is checked by default, see Figure 7.1.1-8. The user can select to uncheck that box which will halt the updates such that the browser page must be refreshed in order to get an update. Under most conditions, the Continuous Update box should remain checked.

Optical Control/Status	System Status	Ethernet Setup	Revision/Update
Optical Control and Status			
Status Parameter	Status		
Power	-24.78 dBm		
Switch Position	No Connection		
Loss of Signal (LOS)	ALARM		
Max	---		
Min	---		
Reference	---		
Temperature (°C)	30.6		
<input checked="" type="checkbox"/> Continuous Update			
Control Function	Setting		
Desired Switch Position	No Connection		
Optical Power Display	dBm		
Loss of Signal (LOS) Level (dBm)	-20.0		
Wavelength	1550		
Mode	Absolute		
Min/Max	Off		
Min/Max and Reference Reset	Reset		

Continuous Update box should remain checked in most cases

**Figure 7.1.1-8 - Continuous Update Box Should Remain Checked Under Most Conditions**

### 7.2 System Status

Clicking on the **System Status** area of the menu bar provides specific module information such as the internal temperature, part number, model number, and serial number, see Figure 7.2-1. A temperature sensor is mounted on the PCB and its value in degrees Celsius is continuously updated on the display.




Figure 7.2-1 - System Status Information

### 7.3 Ethernet Setup

The **Ethernet Setup** menu allows the user to issue a software reboot command to the internal microcontroller and to adjust all Ethernet settings as shown in Figure 7.3-1. The software reboot/reset command should not be necessary unless, as a last resort, the user believes the module cannot recover to normal operation. It should be noted that Figure 7.3-1 shows the factory default setup configuration for the Ethernet port. Also, if the recessed button on the bottom side of the module is pressed, the Ethernet mode and IP address will be reset to this default configuration.




Figure 7.3-1 - Ethernet Setup Controls with Factory Default IP Address

The Ethernet Mode can be set to Static or Dynamic (DHCP) depending on how the user wants to configure the module for Ethernet communication. If the user is connecting directly to a local, standalone computer, a Static IP address should be used. Similarly, if the user wants to assign a


specific IP address, subnet mask, and gateway for connection to an Ethernet Router, the Static configuration must be used. The Dynamic (DHCP) IP addressing mode is used when it is sufficient to allow the Router to assign the IP address. It is important to note that after each of the items (Ethernet Mode, IP Address, IP Subnet, IP Gateway) have been modified, the user must click Apply Settings for the changes to take effect. Table 7.3-1 provides summary details for each of the entries.

**Table 7.3-1 - Ethernet Configuration Description of Parameters**

<b>Parameter</b>	<b>Description</b>	<b>Valid Range</b>
Ethernet Mode	Selects whether the Ethernet port is configured as a Static IP address or a Dynamic IP address. This command must be selected after the desired IP Address, IP Subnet, and IP Gateway have been entered. Once the user clicks "Apply Changes" the Ethernet configuration is immediately changed using the newly entered IP Address, IP Subnet, and IP Gateway.	Static, Dynamic (DHCP)
IP Address	If the Ethernet port is configured as a Static address, this field is used to enter the full IP Address. If Dynamic is selected, this field is not used.	xxx.xxx.xxx.xxx
IP Subnet	If the Ethernet port is configured as a Static address, this field is used to enter the full IP Subnet. If Dynamic is selected, this field is not used.	xxx.xxx.xxx.xxx
IP Gateway	If the Ethernet port is configured as a Static address, this field is used to enter the full IP Gateway. If Dynamic is selected, this field is not used.	xxx.xxx.xxx.xxx

#### **7.4 Revision/Update**

The Revision/Update menu, shown in Figure 7.4-1, allows the user to view the internal microcontroller's firmware revision and also provides the capability to download new firmware when desired. Any new firmware updates must be initiated by first choosing the file, provided by TPC, from the computer then clicking Update to start the file transfer. The download and update process will take approximately 1 minute after which the user can verify the new firmware is running by reading the Firmware Revision which should now be updated to match the newly downloaded version.



**Figure 7.4-1 - Firmware Revision/Update Page, Browse to a File and Click Update to Begin Downloading New Firmware**

When updating the Firmware Revision, once the download has completed the user must click a confirmation window to perform a software reset of the module. After the confirmation has been clicked, the user must close the browser window by clicking the "X" in the upper right hand corner of the browser, wait 30 seconds for the chassis to reboot, then open a new browser window to restart communications.

If an error occurs during the download process, the user will be notified with a Failed indication. The user must then execute the same Firmware download procedure again to correct the failure.

## 8.0 Optical and Electrical Specifications

**Table 8.0-1 – Optical Power Monitor Specifications**

Parameter	Minimum	Typical	Maximum
Insertion Loss (1x16, including external MTP cable)			2.0 dB
Isolation	50 dB		
Switching Time (Hitless)			50 ms
Optical Power Rating			500 mW
Dynamic Optical Power Measurement Range	-50 dBm		+10 dBm
Resolution	±0.01 dB		
Relative Accuracy/Linearity	±0.1 dB		
Absolute Accuracy <sup>1</sup>	±1.0 dB		
Calibration Wavelengths	1310 nm	1550	1610 nm
Fiber Type		SM/MM	
Optical Connectors (standard, others available)		FC and MTP <sup>2</sup>	


Note 1: Single to multi-channel direction is ±1dB, reverse direction is ±2 dB

Note 2: External MTP breakout cable to LC, FC, or other connector type will be quoted separately

**Table 8.0-2 - Electrical, Mechanical, and Environmental Specifications**

Parameter	Minimum	Typical	Maximum
Power Interface (USB or AC/DC Adapter)		+5V	
Operating Current		300 mA	350 mA
Communications Interfaces		USB, Ethernet	
Operating Temperature Range	0 °C		40 °C
Dimensions		6.3" x 3.0" x 1.3"	

## 9.0 Mechanical Dimensions



**Figure 9.0-1 - SW-1016 Module Mechanical Dimensions**

## 10.0 Part Numbers for Ordering

Description	Part Number
SW-1016 Optical Switch	SW-1016 - <input type="checkbox"/> <input type="checkbox"/> <input type="checkbox"/>
Number of Outputs: <b>04, 06, 08, 12, 16, 32</b>	
Single Mode Fiber: <b>S</b> , Multimode Fiber (50/125): <b>M</b>	
1310/1550/1608: <b>A</b> , 1310/1550: <b>S</b> , 850: <b>8</b> , 1550: <b>C</b> , 1310: <b>3</b> , 1610: <b>L</b>	
FC/PC for single port: <b>F</b> , FC/APC for single port: <b>A</b>	
16 fibers of 24 fiber MTP/APC Elite male <sup>1</sup> : <b>M</b>	

*Ordering Information:*



800 Village Walk #316  
 Guilford, CT 06437  
 Ph: 203-401-8093

Email orders to: [sales@xsoptix.com](mailto:sales@xsoptix.com)  
 Fax orders to: 800-878-7282